

**Documentation on CDV-KNX interface / starting
from CDV firmware version V1.2.0
(Document version V1.6 –27.02.20)**

Documentation on CDV-KNX interface / starting from CDV FW version V1.2.0

Note:

The use of the KNX application file Maico_SIM_KWL.knxprod in connection with the KNX module K-SM (0092.0557) is only possible starting from CDV firmware version V1.2.0.

Download the KNX application file <https://www.maico-ventilatoren.com/en/service/downloads>. The KNX project file previously provided to be downloaded, is only supported by the CDV control up to CDV firmware V1.1.1.

For new installations / commissioning of KNX systems, we recommend exclusively the use of the KNX application file Maico_SIM_KWL.knxprod from CDV firmware version V1.2.3. How to perform the firmware update of the CDV controller is described in step 2 of this document.

Notice:

Carrying out the control update to firmware V1.2.0 (or newer) entails reworking the KNX programming (ETS) for CDV units with FW version V1.1.1 (or older) already integrated in the KNX system.

Case: Update of the unit control to V1.2.0. (or newer).

Problem: The CDV unit can no longer be reached via the bus within the KNX system.

Solution 1: The CDV unit is newly integrated into the KNX system using a new KNX application file. -> Programming of the CDV unit within the KNX system must be created again.

Solution 2: Installing the firmware V1.1.2 (Firmware KNX Backup) using the Update Tool of the CDV commissioning software (see step 2 in this document). -> Reprogramming the existing application program on the K-SM is sufficient to integrate the CDV unit into the KNX system again.

In general:

After integration into the KNX bus system, the optional K-SM module functions as any control element on the CDV unit. Regardless of whether the CDV unit is controlled from the control-section or via the KNX module, the last command received remains valid.

Integration of Maico K-SM into the KNX bus system

The construction of a KNX network or the integration of KNX-capable units into a KNX bus system is usually carried out by a system integrator. The programming of such a system (KNX) is only possible by using an ETS software. The application file Maico_SIM_KLW.knxprod is available as a basis for integrating the KNX module in the ETS software. This file can be imported using the import function in the ETS software. Once the process is complete, the imported application file (device file) can be used as the basis for further integration in the KNX system.

Important information:

The failure of the KNX bus voltage has no effect on the CDV unit. The functions of the device are still possible without restrictions.

After restoring the KNX bus voltage, the CDV unit must be switched off and switched back on by means of a device switch to start the K_SM initialization. After the CDV unit has been restarted, it is once again available on the KNX bus without restrictions. **As of CDV firmware version V1.2.3, the initialization of the K_SM takes place automatically after bus voltage failure or bus reset.**

Installing KNX module

The KNX module may only be installed if the unit is de-energised. The unit must be disconnected from the mains before the installation. The installation and activation of the KNX module K-SM must be carried out according to the installation instructions "KNX Module K-SM" (step 1). Further information on integrating the CDV unit into the KNX system is described from step 2 to step 7.




Figure 1: KNX-Modul K-SM (0092.0557)

Step 1

Install and commission the KNX module K-SM according to the enclosed installation instructions "KNX Module K-SM".

Note: KNX module K-SM must be activated by means of CDV commissioning software, touch operating unit or web server under Settings -> KNX. (KNX setting = yes).

Step 2

Perform a control update of the unit control. The firmware update is carried out using the update tool of the CDV commissioning software (from V2.4).

- a. Download the CDV commissioning software at <https://www.maico-ventilatoren.com/en/service/downloads>.
- b. Installation of the software on the PC, laptop.
- c. Connect the CDV control and PC/laptop via USB cable.
- d. Start CDV update. Update the unit control with the latest firmware version (CDV update V1.2.0.Image or newer).

Attention: see page 2!

Step 3

Activate KNX bus power supply. The KNX module is now powered by the KNX bus and can be configured and parameterised using the ETS software.

Step 4

To assign a physical address, the module's programming mode first has to be activated. This is done by pressing the programming button on the KNX module. When the KNX module is in programming mode, its red LED lights up and a physical address can be issued via the ETS software. Once the physical address has been successfully programmed, the LED goes out automatically. Programming mode can also be deactivated manually by pressing the button again.

Step 7

Once the module address has been successfully programmed, the unit can be closed again. To do this, the control console, with the control unit, is hooked into the control box and the unit cover is closed. The power supply to the WS/WR unit can then be reactivated.

Application program and group addresses

If group addresses have been assigned to all the necessary communication objects, the programming of the KNX module can be started. Firstly the ETS software is used to transfer the application program to the KNX module. The application program contains the basic function of the KNX module. The group addresses and parameters are then transferred.

KNX objects list / CDV units starting from firmware version V1.2

Name	Object no.	Function	Type	Flags					Min	Max	Step width	Unit
				K	L	S	Ü	A				
Operating mode	Object 0	Read operating mode	DPT17.001 (scene number)	✓	✓		✓	✓	1	6	1	-
Operating mode	Object 1	Write operating mode	DPT17.001 (scene number)	✓		✓		✓	1	6	1	-
Season	Object 2	Read season	DPT1.001 (switching)	✓	✓		✓	✓	Off	On	-	-
Season	Object 3	Write season	DPT1.001 (switching)	✓		✓		✓	Off	On	-	-
Ventilation level	Object 4	Read ventilation level	DPT17.001 (scene number)	✓	✓		✓	✓	1	5	1	-
Ventilation level	Object 5	Write ventilation level	DPT17.001 (scene number)	✓		✓		✓	1	5	1	-
Intermittent ventilation	Object 6	Read intermittent ventilation	DPT1.001 (switching)	✓	✓		✓	✓	Off	On	-	-
Intermittent ventilation	Object 7	Write intermittent ventilation	DPT1.001 (switching)	✓		✓		✓	Off	On	-	-
Intermittent ventilation – remaining time	Object 8	Read remaining intermittent ventilation time	DPT7.005 (time in seconds)	✓	✓		✓	✓	0	5400	1	sec.
Duration of intermittent ventilation	Object 9	Read duration of intermittent ventilation	DPT7.005 (time in seconds)	✓	✓		✓	✓	300	5400	1	sec.
Duration of intermittent ventilation	Object 10	Write duration of intermittent ventilation	DPT7.005 (time in seconds)	✓		✓		✓	300	5400	60	sec.
Room temperature (actual)	Object 11	Read room temperature	DPT9.001 (temperature in °C)	✓	✓		✓	✓	-	-	0.01	°C
Room temperature (setpoint)	Object 12	Read room temperature	DPT9.001 (temperature in °C)	✓	✓		✓	✓	-	-	0.01	°C

Room temperature (setpoint)	Object 13	Write room temperature	DPT9.001 (temperature in °C)	✓	✓	✓	18	25	0.1	°C
Room temperature KNX	Object 14	Write room temperature via KNX	DPT9.001 (temperature in °C)	✓	✓	✓	0	50	0.1	°C
Max. room temperature (actual)	Object 15	Read maximum room temperature	DPT9.001 (temperature in °C)	✓	✓	✓	-	-	0.01	°C
Max. room temperature (set)	Object 16	Write maximum room temperature	DPT9.001 (temperature in °C)	✓	✓	✓	18	30	0.1	°C
Min. supply air temperature cooling (actual)	Object 17	Read T-supply air min. cooling	DPT9.001 (temperature in °C)	✓	✓	✓	-	-	0.5	°C
Min. supply air temperature cooling (set)	Object 18	Write T-supply air min. cooling	DPT9.001 (temperature in °C)	✓	✓	✓	8	29	0.5	°C
Volumetric flow of supply air (actual)	Object 19	Read current volumetric flow of supply air	DPT9.009 (air throughput in m³/h)	✓	✓	✓	-	-	1	m³/h
Volumetric flow of exhaust air (actual)	Object 20	Read current volumetric flow of exhaust air	DPT9.009 (air throughput in m³/h)	✓	✓	✓	-	-	1	m³/h
Speed of supply air fan (actual)	Object 21	Read current speed of supply air fan	DPT14.033 (frequency Hz)	✓	✓	✓	-	-	0.01	Hz
Speed of exhaust air fan (actual)	Object 22	Read current speed of exhaust air fan	DPT14.033 (frequency Hz)	✓	✓	✓	-	-	0.01	Hz
Supply air temperature	Object 23	Read measurement of supply air temp.	DPT9.001 (temperature in °C)	✓	✓	✓	-	-	0.01	°C
Temperature of outgoing air	Object 24	Read measurement of outgoing air temp.	DPT9.001 (temperature in °C)	✓	✓	✓			0.01	°C
Temperature of air at unit inlet	Object 25	Read measured value temp. of air at unit inlet	DPT9.001 (temperature in °C)	✓	✓	✓			0.01	°C
Temperature of exhaust air	Object 26	Read measurement of exhaust air temp.	DPT9.001 (temperature in °C)	✓	✓	✓			0.01	°C
Relative humidity exhaust air	Object 27	Read humidity value exhaust air	DPT9.007 (humidity %)	✓	✓	✓			0.1	%r.h.
Room sensor external air	Object 28	Write air quality value via KNX	DPT9.008 (parts / million)	✓	✓	✓	0	3000	1	ppm

quality 1			ppm)								
Room sensor external air quality 2	Object 29	Write air quality value via KNX	DPT9.008 (parts / million ppm)	✓	✓	✓	0	3000	1	ppm	
Room sensor external air quality 3	Object 30	Write air quality value via KNX	DPT9.008 (parts / million ppm)	✓	✓	✓	0	3000	1	ppm	
Room sensor external relative humidity 1	Object 31	Write relative humidity value via KNX	DPT9.001 (Humidity %)	✓	✓	✓	0	100	0.1	%r.h.	
Room sensor external relative humidity 2	Object 32	Write relative humidity value via KNX	DPT9.007 (Humidity %)	✓	✓	✓	0	100	0.1	%r.h.	
Time remaining, unit filter	Object 33	Read time remaining for unit filter	DPT7.007 (time h)	✓	✓	✓	✓	-	-	1	Hour (h)
Time remaining, external filter	Object 34	Read time remaining for external filter	DPT7.007 (time h)	✓	✓	✓	✓	-	-	1	Hour (h)
Time remaining, room filter	Object 35	Read time remaining for room filter	DPT7.007 (time h)	✓	✓	✓	✓	-	-	1	Hour (h)
Acknowledge fault	Object 37	Acknowledge fault	DPT1.001 (switching)	✓	✓	✓	Off	On	-	-	
Status of switching contact	Object 41	Read status of switching contact	DPT1.001 (switching)	✓	✓	✓	✓	Off	On	-	-
Status of PTC heating register	Object 42	Read status of PTC heating register	DPT1.001 (switching)	✓	✓	✓	✓	Off	On	-	-
Status of bypass	Object 43	Read status of bypass	DPT1.001 (switching)	✓	✓	✓	✓	Off	On	-	-
Status of brine EHE (ZP1)	Object 44	Read status of brine EHE	DPT17.001 (scene)	✓	✓	✓	✓	1	3	1	-
Position of zone shutter (ZP1)	Object 45	Read position of zone shutter	DPT17.001 (scene number)	✓	✓	✓	✓	1	3	1	-
Status of 3-way air shutter (ZP1)	Object 46	Read status of 3-way air shutter	DPT17.001 (scene number)	✓	✓	✓	✓	1	3	1	-
Status of supplementary heating (ZP1)	Object 47	Read status of supplementary heating	DPT1.001 (switching)	✓	✓	✓	✓	Off	On	-	-
Total operating time	Object 48	Read operating time of CDV (days)	DPT13.100 (time difference s)	✓	✓	✓	✓	0	2 ³¹	1	s
Temperature outside air upstream of	Object 50	Read outside air temperature upstream of EHE	DPT9.001 (Temperature / °C)	✓	✓	✓	✓	-	-	0.01	°C

EHE											
Fault code	Object 112	Read fault code	DPT16.000 (ASCII characters)	✓	✓	✓	✓	0	22	1	-
Information code 1	Object 113	Read information code (information 1)	DPT16.000 (ASCII characters)	✓	✓	✓	✓	0	20	1	-
Information code 2	Object 114	Read information code (information 2)	DPT16.000 (ASCII characters)	✓	✓	✓	✓	0	20	1	-
Information code 3	Object 115	Read information code (information 3)	DPT16.000 (ASCII characters)	✓	✓	✓	✓	0	20	1	-

Communication flags

Flag	Name	Meaning
K	Communication	Object is capable of communication
L	Read	Object can be read
S	Write	Object can receive data
Ü	Transmit	Object can transmit
A	Update	Object can transmit read requests

Used data types

Data type	Description	Length
DPT1.001	Switching	1 bit
DPT7.005	Time (in seconds)	2 bytes
DPT7.007	Time (in hours)	2 bytes
DTP9.001	Temperature (°C)	2 bytes
DPT9.007	Humidity (%)	2 bytes
DPT9.008	Parts/million PPM	2 bytes
DPT13.100	Time difference (seconds)	4 bytes
DPT14.033	Frequency Hz	4 bytes
DPT16.000	Characters (ASCII)	14 bytes
DPT17.001	Scene number	1 byte

Assignment tables for KNX objects

Object 0 / Read operating mode		Object 1 / Write operating mode	
Scene	Meaning	Scene	Meaning

number			number	
1	Off		1	Off
2	Manual		2	Manual
3	Auto time		3	Auto time
4	Auto sensor		4	Auto sensor
5	Eco supply air		5	Eco supply air
6	Eco exhaust air		6	Eco exhaust air

Object 2 / Read season			Object 3 / Write season	
Value	Meaning		Value	Meaning
Off	Winter		Off	Winter
On	Summer		On	Summer

Object 4 / Read ventilation level			Object 5 / Write ventilation level	
Scene number	Meaning		Scene number	Meaning
1	Off		1	Off
2	Humidity protection ventilation		2	Humidity protection ventilation
3	Reduced ventilation		3	Reduced ventilation
4	Nominal ventilation		4	Nominal ventilation
5	Intensive ventilation		5	Intensive ventilation

Object 6 / Read intermittent ventilation			Object 7 / Write intermittent ventilation	
Value	Meaning		Value	Meaning
Off	Intermittent ventilation inactive		Off	Intermittent ventilation deactivated
On	Intermittent ventilation active		On	Activate intermittent ventilation

Object 41 / Status of switching contact			Object 42 / Status of PTC heat register	
Value	Meaning		Value	Meaning
Off	Contact inactive		Off	Bypass inactive
On	Contact active		On	Bypass active

Object 43 / Status of PTC heat register		
Value	Meaning	
Off	PTC heat register inactive	
On	PTC heat register active	

Object 41 / Status of brine EHE (ZP1 additional circuit board)		Object 42 / Status of zone shutter (ZP1)	
Scene number	Meaning	Scene number	Meaning
1	Brine EHE inactive	1	Middle position of shutter
2	Heat brine EHE	2	Shutter: zone 1
3	Cool brine EHE	3	Shutter: zone 2

Object 43 / Status of 3-way air shutter (ZP1)		Object 44 / Status of supplementary heating (ZP1)	
Scene number	Meaning	Value	Meaning
0	Air shutter inactive	0	Supplementary heating inactive
1	Air shutter heating	1	Supplementary heating active
2	Air shutter cooling		

Object 112 / Read fault code			Object 113, 114, 115 / Read information code		
Value	Meaning	Acknowledgment possible	Value	Meaning	
0	No error		0	No information active	
1	Supply air fan	yes	1	Brine EHE, low cooling capacity	
2	Exhaust air fan	yes	2	Communication: EnOcean	
3	Sensor: T-air inlet, unit	no	3	-	
4	Sensor: T-supply air	no	4	Communication: internet	
5	Sensor: T-outgoing air	no	5	Bypass active	
6	Sensor: T-room control unit	no	6	Zone ventilation active	
7	Sensor: T-room external	no	7	Frost protection active	
8	Sensor: T-outside air upstream of EHE	no	8	Frost protection, volumetric flow regulation	
9	Bypass	no	9	Key lock active	
10	Zone shutter	no	10	Filter message: unit	
11	Combination sensor, exhaust air	no	11	Filter message: external filter	
12	Frost protection	no	12	Filter message: room filter	
13	External pre-heating	yes	13	Volumetric flow,	

					measurement active
14	Supply air temperature too cold	no		14	Max. humidity value limit exceeded
15	Exhaust air temperature too cold	no		15	Reheating active
16	Sensor: T-room bus	no		16	Furnace pressure monitor triggered
17	Additional circuit board 1	no		17	External safety shutdown
18	Additional circuit board 2	no		18	Forced operation active
19	Pressure consistency setpoint not reached	yes		19	Communication: ModBus
20	Communication: comfort control unit	no		20	Switching test active
21	System memory	yes			
22	System bus	no			
23	Unknown error	yes			

Configuring the transmission intervals

The transmission intervals of the individual communication objects can be defined in the ETS software. The setting range for the transmission intervals is between 1 and 30 minutes. For example, if a value of 5 is set for the communication object operating mode, the communication object transmits the current object value to the KNX bus every 5 minutes regardless of whether the value has changed or not. A value of 0 deactivates the communication object's interval-controlled transmission function. At the same time, a transmission function is activated should the status of the object value change. The object value is thereby only written to the KNX bus if it changes. Figure 1 shows the window for configuring the transmission intervals of communication objects in the ETS software.

1.1.1 K-SM > Sendezeiten 1

General	Jahreszeit	0	▲▼
Sendezeiten 1	Lüftungsstufe	0	▲▼
Sendezeiten 2	Stoßlüftung	0	▲▼
	Stoßlüftung Restlaufzeit	0	▲▼
	Dauer Stoßlüftung	0	▲▼
	Raumtemperatur Istwert	0	▲▼
	Raumtemperatur Sollwert	0	▲▼
	Max. Raumtemperatur	0	▲▼
	Min. Zulufttemperatur kühlen	0	▲▼
	Volumenstrom Zuluft	0	▲▼
	Volumenstrom Abluft	0	▲▼
	Drehzahl Ventilator Zuluft	0	▲▼
	Drehzahl Ventilator Abluft	0	▲▼
	Temperatur Zuluft	0	▲▼
	Temperatur Fortluft	0	▲▼
	Temperatur Lufteintritt Gerät	0	▲▼
	Temperatur Abluft	0	▲▼
	Relative Feuchte Abluft	0	▲▼

Kommunikationsobjekte Parameter

Figure 2: Configuring the transmission intervals